

Installation Instructions for Merflex[®] PEX OT[®] Faucet and Toilet Supply Lines

IMPORTANT NOTE: Manufacturer assumes no responsibility for failure due to improper installation.

Installation process:

- The water supply line non-bulb end should be clean-cut, squared and bottomed-out in the water shut-off valve to insure a proper seal.
- All fittings and end connections should be free of pipe dope, compounds, sealant and thread tape.
- Metal nuts on a faucet or toilet connection should be hand-tightened and then tightened one (1) additional turn with a wrench. **DO NOT OVER-TIGHTEN.** If plastic nuts are used, they should be firmly hand-tightened and, if required, tightened an additional quarter (1/4) to half (1/2) turn with a wrench. **DO NOT OVER-TIGHTEN.**
- Only the plastic compression sleeve supplied with the supply line should be used for the installation. To install at the water shut off valve, hand-tighten the compression nut, then turn an additional 2 to 3 complete turns with a wrench. **NOTE:** When properly tightened, the compression sleeve should compress the plastic tubing sufficiently to not allow slippage or removal by hand.
- The Merflex PEX OT supply line should not be bent to a radius smaller than 2" for 1/8 CTS X 1/4"OD tubing, 3" for 1/4 CTS X 3/8"OD tubing and 4" for 3/8 CTS X 1/2"OD tubing. Bending the tubing to a radius smaller than recommended can lead to product failure.

CAUTION: This PEX water supply line is recommended for a one-time installation and use. Do not reuse or reconnect. The supply line should be replaced every five years. Do not install or store in direct sunlight as failure may occur.

LIMITATION OF REMEDY AND DISCLAIMER OF WARRANTIES: Manufacturer warrants this product to be free of manufacturing defects. The sole and exclusive remedy for any product proven defective is limited to replacement of the defective product or the refund of the purchase price paid. No other warranty or guarantee of any kind is made by Manufacturer, expressed or implied, statutory, by operation of law or otherwise. **ALL IMPLIED WARRANTIES INCLUDING THOSE FOR MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED.**